

MAINTENANCE PROCEDURES



Pages 49 thru 54

MAINTENANCE and OPERATIONAL PROCEDURES

DAILY MAINTENANCE, VISUAL INSPECTIONS AND OPERATIONAL PROCEDURES

DAILY CHECKLIST

1. Clean debris from Soccer area (pit, stalls, etc...)
2. Visually inspect the coin box for damage and repair as necessary.
3. Visually inspect Soccer stalls for any holes in netting, properly hung back stop pads. Repair if necessary.
4. Walk the inside perimeter of the cage visually checking for ripped netting ties at lower fence, holes in net (including overhead), broken cables, and fencing connections.
5. Visually check Soccer machine area (the pit) for netting holes, rips in netting tie downs, etc. Repair if needed.
6. Visually check where balls are rolled through the Netting Holes. Balls must pass through the middle of the holes (not closer to any edge of hole). Make adjustments to net holes as needed.
7. Visually check light box warning lights for proper operation. Replace any broken lens or defective light bulbs.
8. Visually check 90 degree drop for proper alignment with ball chute. Check proper spacing between ball drop from 90 degree drop and top of ball chute. Proper spacing is 4-1/2" inches. Adjust as necessary.
9. Visually inspect ball chutes for proper alignment.
10. Visually inspect pinch roller wheel for damage or wear. Replace if necessary.
11. Visually inspect Soccer wheels for damage or wear. Replace if necessary.
12. Visually check guide chute "micro switch" cord from light box for proper attachment. Be certain that each wire lead has a properly attached crimp-on "fork terminal" and that it is firmly connected to the micro switch leads. Replace "wire ties" that attach micro switch wire to ball guide chute if broken.
13. Manually feed balls through Soccer machine and watch carefully for accurate rolls and make adjustments as necessary. Drop a token in each coin box and count the number of pitches to assure micro switch is counting correctly. Check for proper sequencing of light box. [Section of Trouble Shooting Guide page 22](#)
14. Turn on hopper/feeding system and observe its operation.
15. Visually check underneath fiberglass shroud at the bottom of the conveyor system before the machines have been turned on for any debris that could block the conveyor.
16. Visually check balls for excessive or uneven wear, cracks or breaks. Replace as needed. Remember, never mix different sizes of balls.
17. **WHENEVER SERVICING OR CONDUCTING INSPECTIONS, ALWAYS KEEP LOOSE CLOTHING AND LONG HAIR AWAY FROM ANY MOVING PARTS! SERIOUS INJURIES COULD RESULT!**
18. See section "Daily Operational Forms & Checklists".

IF YOU HAVE ANY QUESTIONS ABOUT ANY OF THESE INSPECTIONS OR PROCEDURES AFTER REVIEWING AND CHECKING FOR MALFUNCTIONS, CALL "ABC" IMMEDIATELY @ 1-800-578-2243

MAINTENANCE and OPERATIONAL PROCEDURES

WEEKLY MAINTENANCE SCHEDULE and OPERATIONAL PROCEDURES

1. Wash entire soccer cage floor.
2. With soccer machine turned off, remove belt cover and check condition of belt. Then check the variable speed pulley assembly for expansion and contraction by pushing the outside of the pulley assembly back and forth. The sides of the pulley will slide back and forth over the shaft of the pulley. If the pulley is “sticky” or does not move freely, lubricate the grease fitting with one pump of grease from the grease gun. Note: Soccer Range locations with dry or sandy areas should be certain to check these pulleys weekly.
3. Check tension of BALL conveyor. Loosen or tighten as needed.

MONTHLY MAINTENANCE SCHEDULE

MONTHLY MAINTENANCE AND OPERATIONAL PROCEDURES

1. Grease pillow blocks at both ends of the conveyor.
2. Lubricate shaft bearings - one pump every month per bearing. DO NOT OVER GREASE- this can reduce the life of the bearing.
3. Lubricate variable speed pulley every 3-4 weeks, approximately 4 pumps per grease fitting, then run speed of machine up and down 3-4 times to distribute the grease.
4. Overall visual and audio inspection every month checking for loose bolts, worn belts, loud bearings, etc...
5. Clean debris from sump area below fiberglass shroud.
6. Check roof over soccer machines for broken wood, Repair as necessary.
7. Check lighting for all cages.
9. All soccer stall gates must have auto-closing springs. Check them for proper tension (If your gates do not have auto-closing springs, install them). Check for gaps in gates where balls could escape and adjust as necessary.
10. Clean dust off soccer machine motors.

**IF YOU HAVE ANY QUESTIONS ABOUT ANY OF THESE INSPECTIONS OR PROCEDURES
AFTER REVIEWING AND CHECKING FOR MALFUNCTIONS,
CALL “ABC” IMMEDIATELY @ 1-800-578-2243**

MAINTENANCE PROCEDURES

MAINTENANCE SCHEDULE

SOCCER MACHINE	Daily	Weekly	2 Weeks	Monthly	3 Months	6 Months	As Needed
SHAFT BEARING - LUBRICATION (1 PUMP)				√			
VARIABLE SPEED PULLEY - LUBE (3 PUMPS)			√				
CRANK HANDLE - LUBRICATION				√			
MOUNTING SADDLE - LUBRICATION					√		
SHAFT BEARING SET SCREWS				√			
ROLLING ACCURACY	√						√
WHEEL WEAR		√					
WHEEL CLEANING			√				
DRIVE BELT INSPECTION		√					
MOTOR INTAKE VENT CLEANING (ONLY ON "OPEN DRIP PROOF MOTORS")				√			
CHECK 90 DEGREE DROP ADJUSTMENT WITH BALL CHUTE	√						

CONVEYOUR SYSTEM	Daily	Weekly	2 Weeks	Monthly	3 Months	6 Months	As Needed
PULLEY BEARINGS - LUBE (1-2 PUMPS)						√	
CONVEYOR BELT TENSION							√
POWER CORD INSPECTION		√					
90 DEGREE DROP ALIGNMENT	√						
PINCH ROLLER WHEEL ADJUSTMENT		√					
PINCH ROLLER WHEEL SET SCREW			√				
PINCH ROLLER ELECTRICAL CONNECTIONS	√						

MAINTENANCE PROCEDURES

LIGHT BOX	Daily	Weekly	2 Weeks	Monthly	3 Months	6 Months	As Needed
BROKEN RED/AMBER LENSES	√						
LIGHT BULBS	√						
POWER CORDS		√					
ELECTRICAL CONNECTIONS		√					
CIRCUIT BOARD MOUNTING SCREWS				√			
DOOR CLAMPS							√



NETTING	Daily	Weekly	2 Weeks	Monthly	2 Months	6 Months	As Needed
CABLE - ADJUSTMENTS							√
HOLE REPAIR							√
NET SLACK (FROM STRETCHING)							√
BALL EXIT HOLE ALIGNMENT	√						

GENERAL	Daily	Weekly	2 Weeks	Monthly	2 Months	6 Months	As Needed
SELF CLOSING GATE DOORS	√						
WARNING SIGN CONDITION		√					
CHECK BALL CONDITION	√						

COIN BOX	Daily	Weekly	2 Weeks	Monthly	3 Months	6 Months	As Needed
TOKEN INSERT CLEANING				√			
ELECTRICAL CONNECTIONS		√					

SERVICE PROCEDURES

Classification of part orders
All part orders classified into two groups



* - All parts not returned within 30 days are subject to charges.