



MAIN MAST MUST BE RIGGED PRIOR TO ERECTION. BE SURE TO INSTALL COLLAR, ROPE, WINCH ASSEMBLY AND PULLEY ASSEMBLY. SEE NOTES BELOW FOR ATTACHMENT OF CABLE AND ROPE.

PULLEY ASSEMBLY
N.T.S.

NOTE:
ALIGN WINCH WITH PULLEY SO CABLE GOES STRAIGHT UP MAINMAST AND THRU PULLEY ASSEMBLY.

ROUTE CABLE FROM WINCH ASSEMBLY TO MAINMAST COLLAR. FEED CABLE UP THRU THE RECTANGULAR SLOT ON THE COLLAR, THRU THE PULLEY, DOWN THRU THE 5/8" HOLE, THRU THE TWO HOLES IN THE TRIANGULAR GUSSET, AND CLAMP AS SHOWN IN DRAWING.

NOTE:
50'(15.24M) ROPE TIE TO HOOK LEVER

Cable and Winch Detail